






MERCER

M 33C. MASTER CONTROL PANEL

CODE NO. N22

PART NO.	DESCRIPTION
N 0	ELECTRIC WIND MASTER LOCK ASSEMBLY SEE SPARE PARTS LIST N 10
N 7	ADVANCE MECHANISM ASSEMBLY SEE SPARE PARTS LIST N 7
N 10	RETARD MECHANISM ASSEMBLY SEE SPARE PARTS LIST N 10
N 22	SILENT INCREASE MOVEMENT ASSEMBLY SEE SPARE PARTS LIST N 22
13988	HOURLY HAND & BOSS
13989	MINUTE HAND & BOSS
13991	ADVANCE & RETARD POINTED ASSEMBLY
13993	PRESS BUTTON KNOB
13994	ADVANCE & RETARD KNOB
13995	ADVANCE & RETARD MOUNTING PANEL
13996	TERMINAL
13998	RELAY CONTACT - 1 SET
13999	RELAY COIL ASSEMBLY WITH BLADE & ARMATURE
14000	RELAY ASSEMBLY - COMPLETE
14001	CONDENSER - 1 MFD
14002	CONDENSER - 2 MFD
14996	GLASS
14997	INNER BEZEL
16218	CONTROL PANEL CASE
16219	DIAL
A	UNIVERSAL CONNECTOR STRIP
B	RESISTANCE



WHEN ORDERING SPARES QUOTE:

PART NO. 14001 & 14002 - CAPACITY REQUIRED

PART A - NUMBER OF CONNECTIONS REQUIRED

PART B - VALUE OF RESISTANCE

IMPORTANT: QUOTE THE NAME OF VESSEL FOR WHICH SPARES ARE REQUIRED

THOMAS MERCER LTD.
ST. ALBANS
ENGLAND